

User Manual

EDGE® Full Kit



EDGE Mount



EDGE Wireless Charger



EDGE Light

EDGE® Mount

<p>1</p> <p>Use the Magnetic Disc Aligner to stick the Magnetic Disc (A) on the back of your phone.</p>	<p>2</p> <p>Remove the nano suction's protective film.</p>	<p>3</p> <p>Clean the surface of the device before proceeding. Open the EDGE Mount and snap your phone on it, find the position you prefer on your device and push part B for 10 seconds to fix it in place.</p>	<p>4</p> <p>To remove the EDGE Mount pry with EDGE Remover on the lower right side. Never pull the EDGE Mount from part C.</p>
---	--	--	--

EDGE® Wireless Charger







<p>1</p> <p>Use the Magnetic Disc Aligner to stick the Magnetic Disc (A) on the back of your phone (not needed for iPhone 12 or later). To center it, use the Magnetic Disc Aligner.</p>	<p>2</p> <p>Snap the EDGE Wireless Charger to the EDGE Mount and plug the USB-C connector in a USB-C power source.</p>	<p>3</p> <p>Snap your phone to the EDGE Wireless Charger to start charging your phone.</p>
--	--	--

EDGE® Light




<p>1</p> <p>Snap the EDGE Light to the EDGE Mount and click the button to light it up. The first three clicks change the light intensity and the fourth turns it off.</p>	<p>2</p> <p>The EDGE Light works for 55 minutes at medium intensity when fully charged. To recharge the EDGE Light use the USB-C to USB-C cable provided in the pack. You can also keep it plugged in while using it.</p>
---	---

Warnings and Specifications

Warnings

-  KEEP THE DEVICE OUT OF REACH OF CHILDREN.
-  KEEP THE DEVICE AWAY FROM FIRE AND HIGH TEMPERATURE.
-  AVOID DROPPING THE DEVICE.
-  DO NOT SUBMERGE IN WATER OR EXPOSE TO ADVERSE WEATHER CONDITIONS.
-  DO NOT OPEN OR PUNCTURE IT.
-  DO NOT DISPOSE OF LITHIUM POLYMER BATTERY WITH GENERAL WASTE. PLEASE DISPOSE OF IT IN A BATTERY RECYCLING COLLECTION POINT.

Specifications

	<p>EDGE® MOUNT</p> <ul style="list-style-type: none"> · SIZE: 115X30X4.5 mm / 4.5X1.1X1.7 in · MATERIALS: CNC MACHINED ALUMINIUM, WITH N52 MAGNETS AND AN ULTRA GRIPPING LAYER ON THE FRONT SURFACE · WEIGHT: 34 gr / 1.1 oz
	<p>EDGE® UNIVERSAL WIRELESS CHARGER</p> <ul style="list-style-type: none"> · SIZE: Ø56X6 mm / Ø2.2X0.2 in · MATERIALS: CNC MACHINED ALUMINIUM, BASALT GREY WITH N52 MAGNETS · INPUT: 5V/2A, 9V/2A, 12V/1.5A · OUTPUT: 7.5W / 10W / 15W · WEIGHT: 38 gr / 1.3 oz
	<p>EDGE® LIGHT</p> <ul style="list-style-type: none"> · SIZE: Ø56X11 mm / Ø2.2X0.4 in · MATERIALS: CNC MACHINED ALUMINIUM, BASALT GREY · BRIGHTNESS: 280 LUMENS WITH X3 LEVELS OF CONTROL · INPUT: 5V / 1A · BATTERY CAPACITY: 140mAh / 0.5Wh · WEIGHT: 35gr / 1.2oz

Certifications

